for series 9000 actuators





The auxilary switches are used to signal end positions.

The S1 switch is mounted in the actuator in order to determine the final position of the actuator with a potential-free contact.

OPERATION / INSTALLATION POSITION

The device must not be used outside the specified field of application. It may only be installed by suitably trained personnel. Any legal regulations or regulations issued by authorities must be observed during installation.

The device may only be opened at the manufacturer's site. It does not contail any parts that can be replaced or repaired by the user. The cable must not be removed from the device.

The device contain electrical and electronic components and is not allowed to be disposed of as household refuse. All locally valid regulations and requirements must be observed.

It can be used on several models of series 9000 actuators: 9xxx M/K.

| Code | Туре |
|-------|-------------------------------|
| 52214 | Auxiliary switch S1 S9000 90° |
| 52215 | Auxiliary switch S1 S9000 60° |

TECHNICAL DATA: AUXILIARY SWITCH

Rating: max 1(1)A, 230V Material: **PBT**

Temp. range: +55°

S1 AUXILIARY SWITCH





LAYOUT AND WIRING DIAGRAM

S1 AUXILIARY SWITCH ASSEMBLY ON THE ACTUATOR
























Koroška cesta 56 SI-3320 Velenje SI OVENIA

email: web:

+386 3 898 35 35



3. step